AMBA9 QUICK START GUIDE

BUTTONS/FUNCTIONS



BEFORE USE: FULLY CHARGE THE UNIT



Connect the charging cable securely to the AMBA9 GPS Golf Watch.



When securely connected, charging message will display on screen. When charge is complete, the dislay will turn off. Unplug the cable.



Hold button A to power on. Check the main screen to see if the unit is fully charged. "100%" will display in top left corner of screen.

SET DISTANCE INDICATOR TO YARDS



Scroll to gear icon by pressing button C or D to acces the Setting menu. Press button A.



Press button C or D to select "Unit" and press button A.



Press button C or D to select "Y yard" and press button A.



Press button B to go back to main screen. Look for "Y" in top right corner to verify.

Go to any tee box at your nearest golf course to test your AMBA9 GPS Golf Watch. If your golf course is not detected, then please contact us by phone or email.

Phone: +1 909 444 2590 Email: sales@amba7.com